

INSTALLATION GUIDE

Product description:

This part is an replaces the bush with the OEM part number A4503330014.

Contents (parts per pack):

- 4 x Polyurethane bushes
- 4 x Stainless steel sleeves
- 4 x Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove original bush. Retaining the outer shell in the bore of arm.
2. Clean any dirt and corrosion from outer shell.
3. Fit supplied mounting washer behind head of the mounting bolt.
4. Insert polyurethane bush into arm with top hat section of bush on the inside of the wish-bone arm.
5. Insert stainless steel sleeve into polyurethane bush.
6. Refit arm. Tension all hardware to manufacturers recommended torque settings.

