



PART NUMBER

PFR1-608 BLK

DESCRIPTION

FRONT ENGINE MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane Insert Bush
- 2 x Aluminium Sleeve
- 2 x Aluminium Sleeve

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tightened to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush from the arm, remembering to clean away any dirt and corrosion.
2. Apply some of the powerflex grease to the bushes and insert them into the place of the previous bushes.
3. Apply some of the powerflex grease to the aluminium sleeves and insert them into the polyurethane bushes.
4. Re-fit engine mount to the vehicle. Tighten all hardware to manufacturers recommended torque settings.



BACK OF CAR



Exploded View

