

POWERFLEX®

PART NUMBER

PFF26-225

DESCRIPTION

UPPER ENGINE MOUNT BUSH INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Insert

1 x Mild Steel Washer

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the engine under tray from the vehicle.
2. Support the engine from underneath the oil sump with a transmission/trolley jack. Use a block of wood or similar to prevent damage.
3. Remove the centre nut from the engine mount using a deep reach socket, and remove the T-shaped bracket.
4. Insert the polyurethane insert, matching the shape of the bush to the void.
5. Place the plated steel washer on top of the polyurethane insert, as shown in figure 2.
6. Refit the T-shaped bracket on top of the washer.
7. Refit the nut and tension all hardware to the manufacturer's recommended torque settings.
8. Remove the jack supporting the engine, and refit the under tray to road test.



Figure 1



Figure 2