



PART NUMBER

PFF32-401

DESCRIPTION

FRONT LOWER ARM FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane A Bushes
- 2 x Stainless Steel Sleeve
- 2 x Polyurethane B Bushes
- 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove original bush from the arm, clean any dirt and rust from bore in arm.
2. Push in the A bush from the outside of the arm, push in the B bush from the inside of the arm. Apply some of the supplied grease to the bore of the bush.
3. Push the sleeve into the bush.
4. Refit arm to the car and tension all hardware to manufacturers recommended torque settings.



B Bush
Inside of Arm

A Bush
Outside of Arm