



## GENERAL INSTRUCTIONS MIT 1

VEHICLE

MITSUBISHI SHOGUN/PAJERO Mk3 99-06

### INSTALLATION GUIDE

#### Product description:

**PFF44-301** - FRONT WISHBONE-UPPER FRONT AND REAR BUSH

**PFF44-302** - FRONT WISHBONE-LOWER FRONT BUSH

**PFF44-303** - FRONT WISHBONE-LOWER REAR BUSH

**PFR44-306** - REAR WISHBONE-UPPER FRONT BUSH

**PFR44-307** - REAR TRAILING ARM FRONT BUSH

**PFR44-308** - REAR TOE/TRACK ARM INNER BUSH

**PFR44-309** - REAR WISHBONE-UPPER REAR BUSH

*Please read the complete fitting instructions and check package components before fitment.*

*These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

*- all work to be carried out by a licenced technician;*

*- all safety precautions adhered to;*

*- wheel alignment to be checked and adjusted as required after any suspension work.*

*All fasteners must be tensioned to manufacturer's torque settings.*

#### Fitting Instructions:

1. All the above bushes use there original outer shells.
2. Remove the wishbone/arm from the vehicle.
3. Leaving the bush in the wishbone/arm remove the centre metal sleeve and rubber from the outer shell.
4. Make sure all the old rubber and dirt has been removed from the outer shell leaving the bore clean ready to accept the new Powerflex polyurethane bushes.
5. Fit the two polyurethane parts into the original outer shell first, these parts should push in by hand.
6. Lubricate the bore and the outer of the stainless steel sleeve and push into the assembled bush.
6. Once all bushes are assembled refit the wishbone/arm back onto the vehicle.
7. Test drive, check wheel alignment and adjust as required.