

INSTALLATION GUIDE

Product description:

Fits BMW E39 5 Series (1996-2004) 535, 540 and M5 models only

Contents (parts per pack):

2 x bushes (2xA & 2xB) 2 x stainless steel sleeve
1 x Grease 2 x washers



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush from the arm, this can be carried out either by leaving the arm on the car if you have a puller or remove the arm from the car and press the bush out.
2. Clean any dirt and corrosion from the arm.
3. Before fitting the new bush please note bush (A) is shorter than bush (B). The longer bush (B) fits against the flat plate of the subframe, the shorter bush (A) faces the tube on the subframe.
4. Push new bushes into the arm.
5. Apply some of the supplied grease to the bore of the bush and outside of the sleeve, push the sleeve into the bush.
6. Refit the arm back into position, before refitting the bolt fit the washer in between the bush (A) and the tube of the subframe. Fit the bolt and tighten to manufacturer's specifications.



Short side & washer

Long side no washer

